## Öã^\dE)@1EŠã\Á`¦ÁÒ•cæÁT[àã°¢ÁFFÁ;ãÁV¦ã^Á`ÁSêlc^EÓ^!lã

## CHRISTIANIA BIKES Aps

Dammegårdsvej 22, DK - 3782 Klemensker CVR / SE / VAT: DK27914667 Tlf. (+45) 56 96 67 00 Fax. (+45) 56 96 67 08 contact@christianiabikes.com www.christianiabikes.com



Sê (ở ĒÓ^ | jā Q @ ÞÁÔ @ ā cã Đạ ÁÓ^ | \* ) ka£i jájedáheábái íáfeá éágg æka£i jájedáheábá íáfeá éágf ^Tæqikaj-{O/æv|o/Ejo/|ajEgo/ Qo/}^ok@d|kego], Ejæo|o/Ejo/|ajEgo/ Qo/}

## Instructions for assembling the Christiania Bikes three-wheeler

- 1. Assemble the rear frame:
  - a. the mudguard
  - b. the rear-wheelc. the chain

  - d. the pedals NB, the left pedal has links tread
  - e. the saddle
  - the steering damper (and if needed the dynamo holder.)
- 2. Place the front box on its front and fit the handlebar to the box using the 4 bolts.
- 3. Fit the bell and the brake lever on the left side of the handlebar; the brake cable follows down along the right side of the handlebar.
- 4. Fit the front wheels with the brakes; observe that the brake bearing plates are held by a bolt M6 thread. (photo 4.b).
- 5. Connect the rear frame to the front by means of the 4 bolts under the box.
- 6. Adjust the safety device for the steering gear: draw down the safety shores into a triangle, push the tube into the head steam and fasten it to the shores using the bolt (photo 6.c).
- 7. Fasten the gear cable to the head tube and to the chain stay. Adjust the gears according to the enclosed manual.
- 8. Adjust the front brakes in the left and right sides using the adjust screws. (photo 8)

## Have a good time!

And a nice riding time.

With the best regards from the Christiania Bikes team.



