


FSC 1450

18-10-2011

POS.	PART NO	ITEM		
1	1810700235	DOOR		
1.1	1814690042	DOOR GASKET		
1.2	1814900011	LOCK WITH KEY		
2	1817700003	HANDLE		
3	1815500025	HOSE 5/8"		
4	1811900059	SPRING HINGE COMPLETE		
5	1811900043	BASE FOR HINGE		
5.1	6617640009	PIN FOR TOP HINGE		
6	1812700054	ROLL BOND EVAPORATOR		
7	1813700236	INTERNAL FAN MOTOR		
8	1814611082	COVER FOR INTERNAL FAN		
9	1022600059	THERMOSTAT K50-L3420 500 MM		
10	1014618062	THERMOSTAT KNOB		
11	1814618017	VENTILATION GRILL BOTTOM		
12	1011908042	BOTTOM HINGE		
12.1	1017640010	PIN FOR BOTTOM HINGE		
13	1014610190	ADJUSTMENT SCREW FOOT		
14	1014610071	ROLLER		
15	1815200122	GRILL COVER FOR COMPRESSOR COMPARTMENT		
16	1813920002	FLUORESCENT TUBE 18W		
17	1813980002	BALLAST 18W		
18	1513912002	STARTER 4-65		
19	1813912008	SOCKET FOR STARTER		
20	1113921002	SOCKET FOR FLUORESCENT TUBE, CANOPY		
21	1817511420	CANOPY		
22	1013916016	SWITCH FOR LIGHT		
23	1013916017	GREEN CONTROL LAMP		
24	1024100002	THERMOMETER		
25	1814676027	COVER FOR CANOPY		
26	1114618027	LEFT AND RIGHT SIDE COVER FOR FRONT OF CANOPY		
27	1815200121	WIRE SHELF FOR PRINT		
27	1815200158	WIRE SHELF WITH WIRE FRONT		
28	1812800080	CONDENSER		
29	1813700206	FAN BLADE		
30	4513700068	EXTERNAL FAN MOTOR		
31.1	1813980006	BALLAST 36 WATT		
31.2	1813920004	FLUORESCENT TUBE 36W		
31.3	1814611088	FLUORESCENT TUBE HOLDER		
31.4	1013940002	SOCKET FOR FLUORESCENT TUBE		
31.5	1814680001	COVER FOR FLUORESCENT TUBE		
33	1014610174	DRIP TRAY		
34	3113000021	DRIER 25 GR		
35	1010800061	COMPRESSOR COMPLETE GL90TB		
36	1817511421	TOP PLATE FOR CANOPY		
40	1014618029	FALSE BOTTOM HINGE		



090925

Explode FSC1450

NordCap®